



Reuse-A-Wall
INTERNAL HOARDING SYSTEMS

REUSE-A-WALL™ INTERNAL HOARDING SOLUTION

STANDARD PANEL

INSTALLATION GUIDE

COMPONENTS



Adjustable Prop



Double Coupler

Tel: 0844 848 4166
Fax: 0844 848 4188
email:
info@reuseawall.com
website:
www.reuseawall.com

REUSE-A-WALL Internal Hoarding Systems
A Trading Division of Blok N Mesh
Registered office:
Leytonstone House, Leytonstone, London E11 1GA
Company Registration Number 2850152.

Copyright Blok N Mesh 2010



Put the first Reuse-A-Wall Prop Base into place.



With a colleague position the first Panel and secure with the Reuse-A-Wall Prop Top Section and tighten the retaining bolt

REUSE-A-WALL™

STANDARD PANEL



Reuse-A-Wall
INTERNAL HOARDING SYSTEMS

REUSE-A-WALL™ INTERNAL HOARDING SOLUTION

STANDARD PANEL

INSTALLATION GUIDE



Tel: 0844 848 4166
Fax: 0844 848 4188
email:
info@reuseawall.com
website:
www.reuseawall.com

REUSE-A-WALL Internal Hoarding Systems
A Trading Division of Blok N Mesh
Registered office:
Leytonstone House, Leytonstone, London E11 1GA
Company Registration Number 2850152.

Copyright Blok N Mesh 2010

Install a joining section.

REUSE-A-WALL™

STANDARD PANEL



Reuse-A-Wall
INTERNAL HOARDING SYSTEMS

REUSE-A-WALL™ INTERNAL HOARDING SOLUTION

STANDARD PANEL

INSTALLATION GUIDE

REUSE-A-WALL™

STANDARD PANEL



Repeat this process placing a 'Prop centrally in each Reuse-A-Wall Panel.



Install a Security Joining Coupler midway from the top and bottom of the system and repeat throughout.

Tel: 0844 848 4166
Fax: 0844 848 4188
email:
info@reuseawall.com
website:
www.reuseawall.com

REUSE-A-WALL Internal Hoarding Systems
A Trading Division of Blok N Mesh
Registered office:
Leytonstone House, Leytonstone, London E11 1GA
Company Registration Number 2850152.

Copyright Blok N Mesh 2010